Unpacking Instruction :




Figure 1

1. Remove the wrapping film and outer flute and cut the packing tape, as shown in Figure 1;




Figure 2

2. Remove the top cover, detach the enclosure sealing tape, and remove the carton, as in Figure 2;




Figure 3

3、the unpacking rack from the component glass surface or backplane surface into the bottom of the tray, from the tray on both sides of the foot of the pier position will be pulled out of the four stopping rod fixed, cut all the transverse packing tape as shown in Figure 3;




Figure 4

4、When there are 1-2 vertical straps left, slowly push the assembly to lean against the frame, cut the remaining straps, make the assembly lean against the frame, and carry the assembly according to the sequence, as in Figure 4.